



CMP (SILO MOUNT ASSEMBLY)



Dimension

CMP (SILO MOUNT ASSEMBLY)



| Cap. tr | A | A' | B | B' | C | D | E | F | G | H | I | J |
|---------|-----|-----|-----|-----|----|-----|------|-----|-----|------|-----|-----|
| 20/25 | 250 | 250 | 250 | 250 | 24 | 225 | 27.5 | 180 | 180 | 27.5 | 180 | 180 |

All dimensions are in mm.

NOTE: For (30 & 40) tf capacities contact Sensotech

SENSOTECH

2/675." THE PALMS",1st cross Street,Ranga Reddy Gardern,Neelankarai, Chennai-600041

Tel: +19- 44943305 /9176370667/7305716667

Email : sales@sensotechindia.com /sensotechindia@gmail.com

Website: www.sensomaticloadcell.com / sensomaticloadcell.net