


DESB (TRUCK SCALE ASSEMBLY)



Dimension

DESB (TRUCK SCALE ASSEMBLY)



Cap. tf	A	A'	B	B'	C	C'	D	E	F	G	H	I	J
22.5 - 34	180	450	190	320	20	25	285	M16x2.0	132	400	M20x2.5	90	90

All dimensions are in mm.

NOTE: For (45 - 100) tf capacities contact Sensotech

Sensotech

2/675, " THE PALMS", 1st Cross Street, Ranga Reddy Garden, Neelankarai, Chennai-600115
(+91) - 9176070667 / 9790922667 / 9952020667 / 9566022667

Mail : sales@sensotechindia@gmail.com / sensotechindia@gmail.com

Website : <https://sensomatic.co> / <https://sensomaticloadcell.net>