


## SESB (SILO MOUNT ASSEMBLY)



## Dimension

### SESB (SILO MOUNT ASSEMBLY)



Cap. tf	A	A'	B	B'	C	C'	D	E	F	G	H	I	J
0.5 - 2.5	125	150	125	125	16	12	130	14	90	50	14	90	90

All dimensions are in mm.

NOTE: For (3 - 11.5) tf capacities contact Sensotech

### Sensotech

2/675, " THE PALMS", 1st Cross Street, Ranga Reddy Garden, Neelankarai, Chennai-600115  
(+91) - 9176070667 / 9790922667 / 9952020667 / 9566022667

Mail : sales@sensotechindia@gmail.com / sensotechindia@gmail.com

Website : <https://sensomatic.co/> / <https://sensomaticloadcell.net>